

The below table will help you find what size cabinet best fits the PAN assembly and main switch you need.

The best way to navigate this table is to find the PAN and main switch size you need (horizontal rows) and then, work out what cabinet size fits the PAN assembly (the vertical column it falls into). bear in mind there is both 63A and 100A main switch options.

*The bold text denotes the standard size we would recommend.*

Please give us a call for pricing and availability or, if you need help with this table.

<b>500x500</b>		<b>625x500</b>								
<b>4TP 63A</b>	4TP 63A									
<b>4TP 100A</b>	4TP 100A			<b>750x500</b>						
<b>6TP 63A</b>	<b>6TP 63A</b>	6TP 63A								
<b>6TP 100A</b>	<b>6TP 100A</b>	6TP 100A			<b>875x500</b>					
<b>8TP 63A</b>	<b>8TP 63A</b>	8TP 63A	8TP 63A							
<b>8TP 100A</b>	<b>8TP 100A</b>	8TP 100A	8TP 100A			<b>1000x500</b>				
	<b>10TP 63A</b>	<b>10TP 63A</b>	10TP 63A	10TP 63A						
	<b>10TP 100A</b>	<b>10TP 100A</b>	10TP 100A	10TP 100A			<b>1125x500</b>			
	<b>12TP 63A</b>	<b>12TP 63A</b>	12TP 63A	12TP 63A	12TP 63A					
	<b>12TP 100A</b>	<b>12TP 100A</b>	12TP 100A	12TP 100A	12TP 100A	12TP 100A			<b>1250x500</b>	
		<b>14TP 63A</b>	14TP 63A	14TP 63A	14TP 63A	14TP 63A				
		<b>14TP 100A</b>	14TP 100A	14TP 100A	14TP 100A	14TP 100A				
		<b>16TP 63A</b>	<b>16TP 63A</b>	16TP 63A	16TP 63A	16TP 63A				
		<b>16TP 100A</b>	<b>16TP 100A</b>	16TP 100A	16TP 100A	16TP 100A				
			<b>18TP 63A</b>	<b>18TP 63A</b>	18TP 63A	18TP 63A				
			<b>18TP 100A</b>	<b>18TP 100A</b>	18TP 100A	18TP 100A				
			<b>20TP 63A</b>	<b>20TP 63A</b>	20TP 63A	20TP 63A				
			<b>20TP 100A</b>	<b>20TP 100A</b>	20TP 100A	20TP 100A				
				<b>24TP 63A</b>	24TP 63A	24TP 63A				
				<b>24TP 100A</b>	24TP 100A	24TP 100A				